
INSTALLATION INSTRUCTIONS

Package Contains: Tub Spout #185-S

Tools Needed

- Wrench • Teflon Tape •



1. Remove your present tub spout by using an open end wrench and turning counter-clockwise. You will see a pipe protruding from the wall which is either half inch or three quarter inch. If it is a half inch pipe then installation will require the use of the 3/4" X 1/2" face bushing that is already attached to the spout. If the pipe is three quarter inch, then the face bushing should be removed from the spout.
2. Apply teflon tape to spout threads and thread the new tub spout on the pipe. Turn clockwise as far as you can by hand. Then carefully use a wrench and turn once more. Be sure to pad the chrome before using the wrench to prevent damage to the finish. **NOTE: It might be desirable to shorten the pipe nipple protruding from the wall so the new spout is flush to the wall.**
3. Assemble riser pipe to the riser coupling assembly on the spout by tightening the coupling nut. After hand tightening, fasten securely by using a wrench.