

Instructions on installing the off-the-wall wall-mount faucet system (US Utility Patent Pending)

Step 1: Align the back splash case to the top, back of the vanity and screw in the machine screws using the allen wrench until tightened.



Step 2: The spacer blocks are pre-installed as shown in the picture. **Using this default configuration allows you to fit Danze wall mount rough in model D106800BT.** If you prefer to use other brands, you might need to manipulate the spacer configurations/ locations/number of spacers and secure the spacer blocks onto the protruded substrate before you can mount the other rough in valves.



Step 3: Connect the flex water supply lines to the rough in, let them go through the 2 holes at the bottom of the case as shown. Then insert the rough in valve stems through the 3 holes on the back splash.



Step 4: Screw in wood screws through the back of the mounting plate into the spacers. You are now completed with the off-the-wall wall-mount system (installation time about 10 min.). Follow the instruction for the faucet trim to complete the faucet installation.

