

INSTALLATION INSTRUCTIONS

Tools Needed

- Screwdriver • Drill & Bits • Level •
- Wrench • Pencil • Tape Measure • Plumbers Putty •

Parts Included

- 1 Basin • 2 Wall Anchors • 2 Screws • 2 Caps

Be sure to re-inforce wall before installation. We recommend a 2"x12" securely fastened to wall studs at the desired height for your installation.



Wall Hung Installation

1. Determine the height you want. Place basin against the wall. Use a level to make sure both sides are level.
2. Mark the location of mounting holes on the wall.
3. Remove the basin from the wall. **Wall should be reinforced before continuing.**
4. Start to drill hole in **2"x12" re-inforced wall** for mounting screws. If drill bit hits a stud, mount bracket and bolts using large wood screws.
5. Hold basin on wall brackets and ensure that it is level.
6. Connect trap and drain assembly as described by the manufacturer.

NOTE:

DO NOT over tighten or you may damage basin.