

TOILÈChic™

Installation Instructions

It is very important that the instructions be followed precisely for the proper function of the products. ToileChic™ will not be responsible for improper installation.

Note to Installer: Every ToileChic customer has a personal Customer Service Concierge.

Please notify the Concierge of the date and time of your installation and your personal Concierge will reserve that time to be available to answer your questions.

Tools needed: Only a Drill and metal 3/16 drill bit .

Product needed: Tile caulking

Once your toilet is installed as per the Toto® or Kohler® brand installation instructions, carefully unpack the ToileChic™ from its shipping packing. If there is any damage, please notify us immediately. The metal toilet cover is packed separately and includes the hinge unit and the toilet seat. There are 4 rubber bumps that should be placed equally around the toilet rim. Apply the caulking around the entire rim. Install the toilet bowl cover as you would install any toilet seat: there are two bolts

under the toilet cover that fit into the two holes on the toilet bowl. Place the bolts in the holes and screw on the nuts to secure in place. Carefully and skillfully wipe away the caulking that has oozed out between the toilet bowl and the metal toilet cover. There should be 1/8" of caulking covering the entire rim to insure that no moisture can invade between the rim and the cover. You must make sure of this coverage and bonding.

Remove the back of the ToileChic™. Put the ToileChic™ in front of the toilet and slide it into place. The toilet cover should fit snugly on the front and sides.

The flush mechanism is on the same side as the toilet flush handle and close to it...mounted at the inside of the ToileChic™. Do not move it. Locate the template for the flush handle and you will see a hole in it. Place the template over the flush handle and drill through that hole with the 3/16 drill bit into the toilet's flush handle. Take the end of the flush mechanism that is attached to the ToileChic™ and put it through the top of the hole and bend it perpendicularly to hold it in place. Testing has shown that if it is not bent tight and fully, the mechanism will, over time, work its way loose. You must ensure that it is bent horizontally and tightly against the flush handle so it will not come loose. While it is an easy fix, we do not want to inconvenience our customer.

Place the top on the ToileChic™ and, please show the customer or their staff how to take the top on and off.

Congratulations on a successful installation of ToileChic™

