





FRONT VIEW

SIDE VIEW

TOP VIEW


Do not wax areas where you walk or stand.
 Burning cigarettes will damage the surface.
 Abrasive cleaners or powders must not be used, as they will dull the surface.
 Clean the surrounding surface immediately after using caustic drain cleaners.
 Always test the cleaning solution on an inconspicuous area before applying to the entire surface.
 Do not use wire brushes, sharp objects to remove stains, or other surface blemishes.
 Do not allow solvents such as nail polish remover or acetone to come in contact with the surface.