


ANZZI™

SHOWER DOOR INSTALLATION



For models:
SD-AZ40




Please Note: This is a two person job. The glass doors are extremely heavy and it is highly recommended to use professional installers.

Preparation

1. After opening all boxes and packages, read this introduction carefully. Check that all of the needed parts are included in the package, by marking all the components on the "Detailed Diagram of Tub Door Components". Examine boxes and packages for shipping damage. If the unit has been damaged, has a finishing defect, or has missing parts, please contact our customer support department within 3 business days of the delivery date.
2. If this unit is going to be installed in a new construction, please, install all of the required plumbing and drainage before installing the shower. **Use a competent and licensed (if required by local code) plumber for all plumbing installation**
3. **Please note that you should consult your local building codes with questions on installation compliance standards. Building and plumbing codes may vary by location, and we will be not responsible for code compliance standards for your project.**
4. Please insure that prior to the installation the installation surface is leveled and solid and will be able to support the total weight of the unit. Also make sure the walls are at right angles. While some adjustment in leveling of the door is possible, irregular installation surface level or improper angle of side walls will result in serious problems for your installation. Please, note that some adjustments and drilling might be necessary during the installation process.

Tools Required




Tape Measure



Pencil




Phillips Screwdriver



Drill bit
(Ø 5/16")




Level

















Electric Drill



Hammer




No.	Description	Drawing	Qty	No.	Description	Drawing	Qty
1	ST4*25		8	9	Screw cap		10
2	fixed block		2	10	Water guard strip		2
3	Wall anchor		6	11	Handle		1
4	Wall jamb		2	12	Water guard strip		1
5	ST4*30		6	13	ST4*12		10
6	Vertical jamb		2	14	Hinge		2
7	guide rail		2				
8	Sliding block		2				

NOTE: Unpack your unit carefully and inspect it. Lay it out and identify all parts using the detailed diagram and packing list in your manual as a reference. Before discarding the carton, check for small hardware bags that tend to fall to the bottom of the box. If any parts are damaged or missing, please contact us.

Installation steps:

1. Installation of base:


- ① Lay down base.
- ② Check base level, keep it fully flat by padding or rubbing



picture 1

2. Installation of frame:


- ① As picture 2 : insert wall jamb into frame



picture 2

3. Installation of wall jamb:


- ① As picture 3: Adjust with lever, mark drilling hole with pencil , drill hole , and insert rubber seal into the hole
- ② As picture 4: Fix the whole frame onto the wall with ST4*30 screw and screw cap



picture 3


picture 4

4. as picture 5 : ①. Lock vertical jamb and wall jamb with ST4*12 screw and screw cap
②. Adjust moving glass panel to the right place with Allen key ,
check it's smoothness




picture 5

5. as picture 6 : paint glass glue between glass panel and wall for seal



picture 6



Do not use it in 24 hours after glass glue is painted, Ensure the glue is fully dried before using.